



- 1 Mark out the desired location of your In Ground Payment Drop Box. Dig a hole approximately 24" deep by 16" wide.
- 2 Set pedestal in place with the top of the pedestal 34" from finished grade.
- 3 Level and brace the pedestal with 2x4's.
- 4 Pour concrete mix around the pedestal, tapering away from the center.
- 5 Wait for concrete to cure before attaching the cabinet.

### Care instructions

- Clean monthly with an oil-based stainless steel cleaner.
- Polish for a long lasting shine.
- Use a powder graphite or lock lubricant to help the lock work smoothly.