



- 1 Place your On Concrete Payment Drop Box on the level location where you wish to install it.
- 2 Mark out the four holes at the bottom of the cabinet, then remove the cabinet.
- 3 Drill four 1/2" diameter holes, 4" deep. Clear any debris after drilling then realign the cabinet with the holds.
- 4 Ensure the washer is on the bolt and the nut is threaded near the top of each anchor bolt. Insert the four stainless steel wedge anchors into the holes and tap them in with a hammer.
- 5 Tighten each nut with a wrench to fully secure the cabinet. Silicone cover plate around pedestal after installed.

Care instructions

- Clean monthly with an oil-based stainless steel cleaner.
- Polish for a long lasting shine.
- Use a powder graphite or lock lubricant to help the lock work smoothly.