



COVENANT

Security Equipment

www.covenantsecurityequipment.com

CSE-ATX-SSPR BULLET-RESISTANT PACKAGE RECEIVER INSTALLATION INSTRUCTIONS

1. Cut opening in wall 1" larger than outside dimensions of package receiver body.

e.g. SSPR 1414 = 15" x 15" rough opening

Note: SSPR formally SSH is the same product only the name
And model number was changed

2. Slide package receiver through opening until fixed flange of package receiver is tight against threat side of wall (Remove locking arm knob if necessary.)
3. Shim sides and bottom to center package receiver in opening.
4. Install inside adjustable flange over package receiver body and slide up tight against inside wall.
5. Secure adjustable flange to package receiver body. (Weld or bolt.)
Package receiver flanges may also be bolted to wall if desired.
6. The interlock prevents both doors from being opened at the same time.
The interlock is adjusted properly at the factory. No field adjustment is necessary. It is natural for the outside door to have a little play when it is locked. This is the nature of the interlock mechanism and it cannot be adjusted to eliminate the play.
7. Doors are adjusted at the factory; do not attempt to make field adjustments. Do not dismantle the interlock. Please call the manufacturer for help (1-800-880-8306) if there is a malfunction.