

DETAIL A


FIGURE 1

CAUTION:

Use caution when anchoring any other way. All Thread Rods are located in each side jamb. (See DETAIL A)

ANCHOR SCHEDULE		
SUBSTRATE	ANCHOR	MINIUM PENETRATION INTO SUBSTRATE
STEEL (16 GA. MIN.)	1/4" SHEET METAL SCREWS	MIN. PROTRUSION OF 3 THREADS BEYOND FULL ENGAGEMENT
CONCRETE	1/4" DIAMETER CONCRETE SCREW	1.25" INTO CONCRETE
WOOD BUCK	# 14 WOOD SCREW	1.50" INTO WOOD (REQUIRES DOUBLE 2X BUCK)

NOTE: THIS DRAWING EMBODIES A CONFIDENTIAL PROPRIETY DESIGN LICENSED BY COVENANT SECURITY EQUIPMENT. IT IS SUBMITTED UNDER A CONFIDENTIAL RELATIONS ALL PATENT. MANUFACTURING AND SALE RIGHTS REGARDING THE SAME ARE RESERVED EXCEPT TO THE EXTENT RIGHTS ARE EXPRESSLY GRANTED TO OTHERS. THE RECIPIENT AGREES BY ACCEPTING HIP. THESE DRAWINGS NOT TO SUPPLY OR DISCLOSE ANY INFORMATION REGARDING THEM TO ANY UNAUTHORIZED PERSON.



General Notes

Actual Dimension
60"(W) x 53-1/2"(H)

Rough Opening
60-1/2"(W) x 54"(H)

NOTE 1:
Aluminum framing is not
bullet resistant rated.

NOTE 2:
Anchor screws to be
supplied by contractor.

TYPICAL PCJ-130 INSTALLATION

1. Quikserv windows must be installed level & square to work properly.
2. Anchor through each side jambs through the pre-drilled holes. (See FIGURE 1)
3. Recommended height from floor to the bottom of the Window Unit Assembly to be 28". (Check all local & city codes)
4. All other type of anchoring to be approved by certified engineer.



COVENANT

Security Equipment

9323 N. Government Way
Hayden, ID 83835

TITLE: INSTALLATION PROCEDURE

Drawing Name
CSE-QS-PCJ-130 INSTALLATION

DATE	DRAWN BY	SCALE	SHEET	SIZE
6/30/2016	RBV	NTS	1 of 1	A